



STEP NO. 25 INSTALL 02-452-59 CLOTHES ROD BY INSERTING ROD INTO 02-452-32 MOUNTING FLANGE ATTACHED TO WALL PANELS 02-311-47 AND 02-311-48 WITH #10 X 3/8" TAP. SCR. (LS205-6B). SLIP 02-452-32 FLANGE OVER ROD & SECURE TO 02-472-36B & 02-472-17 PARTITION PANELS WITH #8-32 X 7/4" MACH. SCR. (LS68-4B) AND #8-32 CAP NUTS (LS407-8M).

STEP NO. 26 INSTALL (3) 02-471-37 SHELVES SLIP IN PROPER PLACES WITH CLIPS PROVIDED IN SIDE PANELS AND PARTITION PANELS OF LINEN CLOSET.

STEP NO. 27 INSTALL (6) 02-472-36 SHELVES CLIP IN POSITION (3 EACH SIDE OF BEDROOM CLOSETS).

STEP NO. 28 INSTALL 02-472-7 CLOTHES ROD SUPPORTS (1 EA. ROD) TO UPPER SHELF AND FASTEN WITH (1) EACH #10-24 CAP NUT (LS407-10M).

		ERECTION		MANUAL
		TITLE		
PREPARED BY	DATE	EFF		1001 & SUB
G.E.	6-3-49			DRAWING NUMBER EM-02-R-61.1